



QUASIMOTO™

QUASICADE

PRO



OWNER'S Manual

TABLE OF CONTENTS

Introduction.....	2
High Definition Monitor Information.....	2
QuasicadePRO Installation.....	3
Connecting your PS2/Xbox.....	4
Connecting your GameCube.....	5
Connecting your PC.....	6
QuasiCON User's Guide.....	7
Warranty & Support.....	9

INTRODUCTION:

Congratulations and thank you for purchasing the QuasicadePRO Arcade System. The following document contains information to help you enjoy the ultimate arcade experience. The QuasicadePRO is powered by high end video, audio, and gaming components, connecting them all together correctly will ensure that the gaming experience is rich and enjoyable.

HIGH DEFINITION MONITOR INFORMATION :

The QuasicadePRO monitor is capable of running in high definition modes of 480p, 720p, and 1080i. These video modes offer enhanced quality beyond traditional televisions. The video quality of your particular game depends on 1) the type of game system 2) the type of the connection and 3) the software you are using. Not all games or game systems can fully utilize the high definition features of this monitor. The Quasicade monitor still outperforms a traditional television even in non-high definition modes.

In order to get the best quality picture for your game system, you will need to provide the appropriate video connection for your specific game system. The Quasicade Pro includes S-video and component video connections for your video game system. Component (RGB) cables offer a superior video quality. Refer to the following for your specific game system:

Xbox - capable of 480p, 720p, 1081i with the included component cable. Connect the video cables to the component video inputs on the back of the Quasicade monitor. You will need to go to the video settings in the Xbox menu system and turn ON modes 480p, 720p, and 1080i. The Xbox is capable of running the maximum resolution of the monitor, but is specific to the game software you buy. The video resolution for each game is noted on the game case, usually on the back. S-video is the next best option, cable included.

Playstation 2 - capable of 480p. Use the component video cable. Connect the video cables to the component video inputs on the back of the Quasicade monitor. If the video seems distorted, try unplugging the video cable from the back of the PS2, power down, and replug. There is a setting in the menu to enable the RGB mode of the system. S-video is the next best option, cable included.

GameCube - older models of the GameCube support 480p. Newer models discontinued this feature because of a lack of demand. Inquire with your video game retailer regarding these options. We recommend S-video and have included a cable for your Gamecube.

PC - two options for connection, (good) S-video or (best) SVGA. (1) S-VIDEO: you will need a video card with S-video out and a 6 foot standard S-video cable (not included). Turn the settings in the video card to activate the S-video port (you will need to do this with a monitor attached before disconnecting). (2) SVGA: you will need to buy an adapter to convert the SVGA signal to component video. These are available online (see <http://www.smarthome.com/77706.html> for example) or your high end video retailer.


QUASICADEPRO INSTALLATION INSTRUCTIONS:

1. Remove the 4 bolts under the pallet with a wrench. The bolts are 13mm. If you do not have a 13mm wrench we recommend a crescent wrench.
2. Carefully slide the Quasicade to overlap one side of the pallet and insert 2 of the included leg levelers.
3. Move the Quasicade back onto the pallet and slide the other side of the cabinet over the pallet to install the remaining two leg levelers.
4. With two people slide the Quasicade off the pallet.
5. The Quasicade can be dollied from the back.
6. Once the Quasicade is in its final spot, adjust the leg levelers for a level cabinet and plug the power cord into a standard outlet.
7. Use the included shelf rests and install the shelving in the desired location.
8. See the appropriate installation guide for the video game system you are using.

NEVER MOVE OR LIFT THE QUASICADE BY THE CONTROLLER - DON'T VOID YOUR WARRANTY!


9. Plug the game system specific, shorter cables into the Player 1 and Player 2 ports on the game system. Plug the short cable into the longer cable that you connected to the QuasiCON. You may have to swap player one and player two plugs to match the player position on the QuasiCON after turning the system on.
10. Turn on the light. The switch is located inside the cabinet on the left wall. If the marquee does not light, make sure the power strip is on and the power cable from the light box is inserted in the power strip.

Connecting a PS2 or Xbox to the QuasicadePRO:




- ① Connect the component audio/video cable to your PS2/Xbox.
- ② Connect the component connection of the component a/v cable to the back of the monitor as shown above.
- ③ Connect the Red & White audio cables of the universal a/v cable to the RCA to stereo jack adapter.
- ④ Position the wired remote on the keyboard tray and feed the wires into the cabinet storage area.
- ⑤ Connect the 3.5mm stereo jack to the other end of the RCA to stereo jack adapter.
- ⑥ Connect the wired remote connection to the sub-woofer as shown above.
- ⑦ Connect the satellite speakers to the sub-woofer as shown above.
- ⑧ Connect the power cable of the sub-woofer to the surge protector inside the cabinet storage area.
- ⑨ Power on the PS2/Xbox, monitor, and subwoofer. Adjust the volume using the wired remote as desired.
- ⑩ Using the monitor remote or TV/Video button on the monitor, select "Video 1" as the source.
- ⑪ Enjoy your QuasicadePRO arcade system.

Connecting a GameCube to the QuasicadePRO:



- ① Connect the universal audio/video cable to your GameCube.
- ② Connect the S-Video connection of the universal a/v cable to the back of the monitor as shown above.
- ③ Connect the Red & White audio cables of the universal a/v cable to the RCA to stereo jack adapter.
- ④ Position the wired remote on the keyboard tray and feed the wires into the cabinet storage area.
- ⑤ Connect the 3.5mm stereo jack to the other end of the RCA to stereo jack adapter.
- ⑥ Connect the wired remote connection to the sub-woofer as shown above.
- ⑦ Connect the satellite speakers to the sub-woofer as shown above.
- ⑧ Connect the power cable of the sub-woofer to the surge protector inside the cabinet storage area.
- ⑨ Power on the GameCube, monitor, and subwoofer. Adjust the volume using the wired remote as desired.
- ⑩ Using the monitor remote or TV/Video button on the monitor, select "Video 1" as the source.
- ⑪ Enjoy your QuasicadePRO arcade system.

Connecting a PC to the QuasicadePRO



- ① Connect the s-video cable to your video card.
- ② Connect the s-video cable to the Video 1 s-video connection on the back of the monitor as shown above.
- ③ Position the wired remote on the keyboard tray and feed the wires into the cabinet storage area.
- ④ Connect the 3.5mm stereo jack to the audio out on the sound card.
- ⑤ Connect the wired remote connection to the sub-woofer as shown above.
- ⑥ Connect the satellite speakers to the sub-woofer as shown above.
- ⑦ Connect the power cable of the sub-woofer to the surge protector inside the cabinet storage area.
- ⑧ Power on the PC, monitor, and subwoofer. Adjust the volume using the wired remote as desired.
- ⑨ Using the monitor remote or TV/Video button on the monitor, select "Video 1" as the source.
- ⑩ Enjoy your QuasicadePRO arcade system.


CONTROL: INSTALLATION AND USAGE

After placing your game system on the shelf in Quasicade and connecting the audio and video, you will need to connect the arcade controls (QuasiCON) to your game system. See the following page for instructions specific to your game system (Playstation 2, Xbox, GameCube, or PC).


QuasiCON™

Congratulations, you now own the most advanced arcade style controller. The QuasiCON 2P Control System combines advanced technology with the highest grade components. This document will help you to install/change the game system being used with the QuasiCON, and explain all the many features of the QuasiCON and their usage.


Contents:




(1) QuasiCON 2P Control System




(4) controller legends




(2) long universal connector cables




(2) Xbox™ adapter cables



(2) PlayStation™ 2 adapter cables



(2) GameCube™ adapter cables



(2) PC USB adapter cables

Installation

1. Connect the male end of the long universal connector cable to Player 1 connector located the back of the QuasiCON (see diagram of QuasiCON above). Tighten the thumb screws to 'hand tight'. Do not over tighten.
2. Repeat step 1 for the second player connection.
3. (From Step 23) Pass the cables through the slot under the monitor (to access the console storage).

QUASICON INSTRUCTIONS CONTINUED:

Connecting your QuasiCON to PlayStation 2

1. Turn the power off to your PlayStation 2.
2. Connect the female end of the long universal connector cable to the PlayStation 2 adapter cable. Tighten the thumb screws to 'hand tight'. Do not over tighten.
3. Repeat step 2 for the second player connection.
4. Connect the PlayStation 2 adapter cable(s) to the appropriate controller port.
5. Turn the power on to your PlayStation 2.
6. Lift legend cover and insert the PlayStation 2 legend. Close the legend cover.

NOTE: The mode LED will illuminate when connected to a PlayStation 2. Pressing the mode button will change the QuasiCON to digital mode.

Connecting your QuasiCON to Xbox

1. Turn the power off to your Xbox.
2. Connect the female end of the long universal connector cable to the Xbox adapter cable. Tighten the thumb screws to 'hand tight'. Do not over tighten.
3. Repeat step 2 for the second player connection.
4. Connect the Xbox adapter cable(s) to the appropriate controller port.
5. Turn the power on to your Xbox.
6. Lift legend cover and insert the Xbox legend. Close the legend cover.

Connecting your QuasiCON to GameCube

1. Turn the power off to your GameCube.
2. Connect the female end of the long universal connector cable to the GameCube adapter cable. Tighten the thumb screws to 'hand tight'. Do not over tighten.
3. Repeat step 2 for the second player connection.
4. Connect the GameCube adapter cable(s) to the appropriate controller port.
5. Turn the power on to your GameCube.
6. Lift legend cover and insert the GameCube legend. Close the legend cover.

Using the QuasiCON

The QuasiCON operates just like a regular controller for each console. See the controller legend for button placement. Consult your software manual for the exact function of each button, analog stick, and digital stick within the software.

Connecting your QuasiCON to PC

1. Insert Player 1 Connection USB plug into a USB port on the PC.
2. Depending on your settings, you should receive a Windows prompt saying, "QuasiCON Found, Human Interface Device, Windows is loading software for your new device." Allow a few seconds for your system to automatically load the proper drivers.
3. Since the QuasiCON utilizes Windows' controller drivers, it is not necessary to install any additional software.
4. If the "QuasiCON Found" window does not appear, use the "ADD HARDWARE" or "GAME OPTIONS" (or "GAME CONTROLLERS") function in the Control Panel.
5. Repeat steps for Player 2 connection.

Calibrating Analog Sticks

We recommend that you calibrate the analog sticks for optimum performance.

With Windows 98/ME/2000:

- a) Click on the Windows START Button.
- b) Select SETTINGS, then CONTROL PANEL, then GAME OPTIONS.
- c) Select your controller and calibrate the analog sticks for optimum response.

With Windows XP:

- a) Click on the Windows START Button.
- b) Select CONTROL PANEL (At this point select PRINTERS AND OTHER HARDWARE if the Control Panel is set to Category View. If not, go to 'c').
- c) Select GAME CONTROLLERS
- d) Select your controller and calibrate the analog sticks for optimum response.

Digital & Analog Mode

The QuasiCON defaults to analog mode (Mode LED is on). To Change to digital mode, simply press the mode button (Mode LED is off). While in Digital mode, the digital stick is the primary control stick (the analog sticks are disabled) and operates the X & Y axis. While in Analog mode, the left analog stick operates the X & Y axis, the right analog stick operates the R & Z axis, and the digital stick operates as a POV hat switch.

Customizing Buttons

Most games have a default setting for the buttons, but keep in mind that the function of the buttons will change with each game. If you are unhappy with the default button configuration, most games will allow you to change the button configuration. Refer to the game's instruction manual regarding button configuration.


Warranty Information & Technical Support:

Quasimoto backs its products 100%. The Quasicade PRO and QuasiCON is covered by a limited LIFETIME warranty. Any defects or failures due to normal use will be repaired or replaced at Quasimoto's discretion. Abuse to the product is not covered by the limited LIFETIME warranty. Please contact Quasimoto if you ever have any problems with the QuasiCON. To obtain warranty/technical support, please contact Quasimoto technical support via any of the following methods:

Telephone: 1.800.400.5774
Web: www.quasimoto.com
E-mail: tech@quasimoto.com

Hours of operation are Monday through Friday, from 8 AM to 5 PM CST, excluding major holidays. Our technical support staff will do its best to respond to you within 24 hours.

READ THESE INSTRUCTIONS. All safety and operating instructions should be read before the product is operated. Do not use the apparatus near water. Clean product only with dry cloth. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a dry cloth for cleaning. Do not defeat the safety purpose of the polarized or grounding type plug. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus. Unplug this apparatus during lightning storms or when unused for long periods of time. Do not overload outlets and extension cords as this can result in a risk of fire or electric shock. If damaged, unplug the apparatus from the wall outlet and contact Quasimoto immediately.



Quasimoto, Inc. © 2004. Quasimoto, Quasicade, are trademarks of Quasimoto, Inc. PlayStation 2, Xbox, and GameCube are trademarks or registered trademarks of their respective owners.